


# EVERLAST

## POWERPLASMA S SERIES

60-100 Amp S Series IGBT Inverter Platform Plasma Cutters



### ***Operator's Manual for the PowerPlasma S Series (60-100 Amp Models) Safety, Setup and General Use Guide***

Rev. 5 0 000330-18

[everlastwelders.com](http://everlastwelders.com)



1-877-755-9353  
329 Littlefield Ave. South San Francisco, CA 94080 USA

Specifications and Accessories subject to change without notice.

## TABLE OF CONTENTS

| Section.....                              | Page |
|---|------|
| Letter to the Customer .....              | 3    |
| Everlast Contact Information.....         | 4    |
| Safety Precautions.....                   | 5    |
| Introduction and Specifications.....      | 9    |
| Unit Specifications.....                  | 10   |
| General Overview.....                     | 11   |
| General Use and Care.....                 | 11   |
| Quick Setup Guide, Torch Connection.....  | 12   |
| Rear Panel Gas Connection and Wiring..... | 13   |
| Compressor and Air Dryer Diagram.....     | 14   |
| Front Panel Features and Controls.....    | 15   |
| Rear Panel Features and Controls.....     | 18   |
| Basic Theory and Function.....            | 19   |
| PowerPlasma 60S Torch.....                | 23   |
| PowerPlasma 80S Torch.....                | 25   |
| PowerPlasma 100S Torch.....               | 27   |
| CNC Connector Pin-Out.....                | 29   |
| Troubleshooting.....                      | 30   |
| Special Operating Note.....               | 31   |

**NOTE:** Product specifications and features are subject to change without notice. While every attempt has been made to provide the most accurate and current information possible at the time of publication, this manual is intended to be a general guide and not intended to be exhaustive in its content regarding safety, welding, or the operation/maintenance of this unit. Everlast Power Equipment INC. does not guarantee the accuracy, completeness, authority or authenticity of the information contained within this manual. The owner of this product assumes all liability for its use and maintenance. Everlast Power Equipment INC. does not warrant this product or this document for fitness for any particular purpose, for accuracy of performance or for particular suitability of application. Furthermore, Everlast Power Equipment INC. does not accept liability for injury or damages, consequential or incidental, resulting from the use of this product or resulting from the content found in this document or accept claims by a third party of such liability.

**Dear Customer,**

**THANKS!** You had a choice, and you bought an Everlast. We appreciate you as a customer and hope that you will enjoy years of use from your welder.

Please go directly to the Everlast website to register your unit and receive your warranty information. Your unit registration is important should any information such as product updates or recalls be issued. It is also important so that we may track your satisfaction with Everlast products and services. If you are unable to register by website, contact Everlast directly through the sales department via the main customer service number in your country. Your unit will be registered and warranty will be issued and in full effect. Keep all information regarding your purchase. **In the event of a problem you must contact technical support before your welder can be a candidate for warranty service and returned.**

**Please review and download the official warranty statement, located on our website [www.everlastwelders.com](http://www.everlastwelders.com). If you are not in the United States, visit the distributor's website warranty information nearest to your region or country. Print it for your records and become familiar of its terms and conditions.**

Everlast offers full technical support in several different forms. We offer domestic based phone support and online support. Online support is available through email and through our website contact forms. We also provide a welding support forum designed for customers and noncustomer interaction. Technical advisors are active on the forum on a regular basis. We also divide our support into two divisions: technical and welding performance. Should you have an issue or question concerning your unit, please contact performance/technical support available through the main company headquarters available in your country. For best service, call the appropriate support line and follow up with an email. In the event you do not reach a live person, particularly during heavy call volume times, holidays, or off hours, leave a message and your call will normally be returned within 24 hours. For quick answers to basic operating or service questions, join the company owned forum linked through the US website. You should be able to find knowledgeable, helpful people and staff available to answer your questions, and perhaps find a topic that already addresses your question at <http://www.everlastgenerators.com/forums/>.

Should you need to call or write, always know your model name, purchase date and welder manufacturing inspection date. This will assure the quick and accurate customer service. **REMEMBER: Be as specific and informed as possible. Technical and performance advisors rely upon you to carefully describe the conditions and circumstances of your problem or question. Take notes of any issues as best you can. You may be asked a series of questions by the advisors that are meant to clarify problems or issues. Some of these questions may seem basic or fundamental, but even with experienced users technical advisors can't assume that correct operating procedures are being followed for proper operation, and must cover all aspects to properly diagnose the problem. Depending upon your issue, it is advisable to have basic tools handy such as screwdrivers, wrenches, pliers, and even an inexpensive test meter with volt/ohm functions before you call.**

**Please note: To establish a warranty claim and return a unit for repair or replacement, you must call technical support first and go through basic diagnosis before an Return Authorization will be issued.**

Let us know how we may be of service to you should you have any questions.

Sincerely,

Everlast Customer Service



Serial number: \_\_\_\_\_  
Model number: \_\_\_\_\_  
Date of Purchase: \_\_\_\_\_

**Contact Information**

**Everlast US:**

Everlast consumer satisfaction email: [sales@everlastwelders.com](mailto:sales@everlastwelders.com)  
Everlast Website: [everlastwelders.com](http://everlastwelders.com)  
Everlast Technical Support: [support@everlastwelders.com](mailto:support@everlastwelders.com)  
Everlast Support Forum: <http://www.everlastgenerators.com/forums/index.php>  
Main toll free number: 1-877-755 WELD (9353) 9am—5pm PST M-F  
11am-4pm PST Sat.

**FAX: 1-650-588-8817**

**Everlast Canada:**

Everlast consumer satisfaction email: [sales@everlastwelders.ca](mailto:sales@everlastwelders.ca)  
Everlast Website: [everlastwelders.ca](http://everlastwelders.ca)  
Everlast Technical Support: [sales@everlastwelders.ca](mailto:sales@everlastwelders.ca)  
Telephone: 905-637-1637 9am-4:30pm EST M-F  
10am-1pm EST Sat.

**FAX: 1-905-639-2817**

**Everlast Australia:**

Sydney: 5A Karloo Parade Newport NSW 2106  
(02) 9999 2949  
Port Macquarie: 2B Pandorea Place Port Macquarie  
(02) 8209 3389  
After hours support: 0413 447 492  
Everlast Technical Support: [support@pickproducts.com](mailto:support@pickproducts.com)

## **SAFETY PRECAUTIONS**

Everlast is dedicated to providing you with the best possible equipment and service to meet the demanding jobs that you have. We want to go beyond merely delivering a satisfactory product to you. That is the reason we offer free technical support to assist you with your needs should an occasion occur. In the event that you need a repair, or have an issue, please call tech support to initiate a warranty claim and an Return Authorization number if needed. With proper use and care your product should deliver years of trouble free service.



Safe operation and proper maintenance is your responsibility.

We have compiled this operator's manual to instruct you in basic safety, operation and maintenance of your Everlast product to so you may enjoy the best possible operating experience. Most welding and cutting is based upon experience and common sense. As thorough as this welding manual may be, it is no substitute. Exercise extreme caution and care in all activities related to welding or cutting. Your safety, health and even life depends upon it. While accidents are never planned, preventing an accident requires careful planning.

**Please carefully read this manual before you operate your Everlast unit.** This manual is not only written for the safe use of the machine, but also to assist in obtaining the best performance out of your unit. Do not operate this unit until you have read this manual and you are thoroughly familiar with the safe operation of the unit. If you feel you need more information please contact Everlast Support.

The warranty does not cover improper use, maintenance or consumables. **Do not attempt to alter or defeat any safety device of your unit.** Keep all shields and covers in place during unit operation should an unlikely failure of internal components result in the possible presence of sparks and explosions. If a failure occurs, discontinue further use until malfunctioning parts or accessories have been repaired or replaced by qualified personnel.



### ***Note on High Frequency electromagnetic disturbances:***

Certain welding and cutting processes generate High Frequency (HF) energy. These energy waves may disturb sensitive electronic equipment such as televisions, radios, computers, cell phones, and related equipment. High Frequency may also interfere with fluorescent lights. Consult with a **licensed** electrician if a disturbance is noted. Sometimes, improper wire routing or poor shielding may be the cause.



HF can interfere with pacemakers. See EMF warnings in following safety section for further information. Always consult your physician before entering an area known to have welding or cutting equipment if you have a pacemaker.

## SAFETY PRECAUTIONS



These safety precautions are for protection of safety and health. Failure to follow these guidelines may result in serious injury or death. Be careful to read and follow all cautions and warnings. Protect yourself and others.



**Welding and cutting processes produce high levels of ultraviolet (UV) radiation that can cause severe skin burn and damage.** There are other potential hazards involved with welding such as severe burns and respiratory related illnesses. Therefore observe the following to minimize potential accidents and injury:



**Use appropriate safety glasses with wrap around shields while in the work area, even under welding helmets to protect your eyes from flying sparks and debris.** When chipping slag or grinding, goggles and face shields may be required.



**When welding or cutting, always use an approved shielding device, with the correct shade of filter installed.** Always use a welding helmet in good condition. Discard any broken or cracked filters or helmets. Using broken or cracked filters or helmets can cause severe eye injury and burn. Filter shades of no less than shade 5 for cutting and no less than shade 9 for welding are highly recommended. Shades greater than 9 may be required for high amperage welds. Keep filter lenses clean and clear for maximum visibility. It is also advisable to consult with your eye doctor should you wear contacts for corrective vision before you wear them while welding.



**Do not allow personnel to watch or observe the welding or cutting operation unless fully protected by a filter screen, protective curtains or equivalent protective equipment.** If no protection is available, exclude them from the work area. Even brief exposure to the rays from the welding arc can damage unprotected eyes.



**Always wear hearing protection because welding and cutting can be extremely noisy. Ear protection is necessary to prevent hearing loss.** Even prolonged low levels of noise has been known to create long term hearing damage. Hearing protection also further protects against hot sparks and debris from entering the ear canal and doing harm.



**Always wear personal protective clothing.** Flame proof clothing is required at all times. Sparks and hot metal can lodge in pockets, hems and cuffs. Make sure loose clothing is tucked in neatly. Leather aprons and jackets are recommended. Suitable welding jackets and coats may be purchased made from fire proof material from welding supply stores. Discard any burned or frayed clothing. Keep clothing away from oil, grease and flammable liquids.



**Leather boots or steel toed leather boots with rubber bottoms are required for adequate foot protection.** Canvas, polyester and other man made materials often found in shoes will either burn or melt. Rubber or other non conductive soles are necessary to help protect from electrical shock.



**Flame proof and insulated gauntlet gloves are required whether welding or cutting or handling metal.** Simple work gloves for the garden or chore work are not sufficient. Gauntlet type welding gloves are available from your local welding supply companies. Never attempt to weld with out gloves. Welding with out gloves can result in serious burns and electrical shock. If your hand or body parts comes into contact with the arc of a plasma cutter or welder, instant and serious burns will occur. **Proper hand protection is required at all times when working with welding or cutting machines!**

## SAFETY PRECAUTIONS



**WARNING!** Persons with pacemakers should not weld, cut or be in the welding area until they consult with their physician. Some pacemakers are sensitive to EMF radiation and could severely malfunction while welding or while being in the vicinity of someone welding. *Serious injury or death may occur!*



**Welding and plasma cutting processes generate electro-magnetic fields and radiation.** While the effects of EMF radiation are not known, it is suspected that there may be some harm from long term exposure to electromagnetic fields. Therefore, certain precautions should be taken to minimize exposure:

- Lay welding leads and lines neatly away from the body.
- Never coil cables around the body.
- Secure cables with tape if necessary to keep from the body.
- Keep all cables and leads on the same side the body.
- Never stand between cables or leads.
- Keep as far away from the power source (welder) as possible while welding.
- Never stand between the ground clamp and the torch.
- Keep the ground clamp grounded as close to the weld or cut as possible.



**Welding and cutting processes pose certain inhalation risks.** Be sure to follow any guidelines from your chosen consumable and electrode suppliers regarding possible need for respiratory equipment while welding or cutting. Always weld with adequate ventilation. Never weld in closed rooms or confined spaces. Fumes and gases released while welding or cutting may be poisonous. Take precautions at all times.

Any burning of the eyes, nose or throat are signs that you need to increase ventilation.

- Stop immediately and relocate work if necessary until adequate ventilation is obtained.
- Stop work completely and seek medical help if irritation and discomfort persists.



**WARNING!** Do not weld on galvanized steel, stainless steel, beryllium, titanium, copper, cadmium, lead or zinc without proper respiratory equipment and or ventilation.



**WARNING!** This product when used for welding or cutting produces fumes and gases which contains chemicals known to the State of California to cause birth defects and in some cases cancer.

(California Safety and Health Code §25249.5 *et seq.*)



**WARNING!** Do not weld or cut around Chlorinated solvents or degreasing areas. Release of Phosgene gas can be deadly. Consider all chemicals to have potential deadly results if welded on or near metal containing residual amounts of chemicals.



**Keep all cylinders upright and chained to a wall or appropriate holding pen.** Certain regulations regarding high pressure cylinders can be obtained from OSHA or local regulatory agency. Consult also with your welding supply company in your area for further recommendations. The regulatory changes are frequent so keep informed.



**All cylinders have a potential explosion hazard.** When not in use, keep capped and closed. Store chained so that overturn is not likely. Transporting cylinders incorrectly can lead to an explosion. Do not attempt to adapt regulators to fit cylinders. Do not use faulty regulators. Do not allow cylinders to come into contact with work piece or work. Do not weld or strike arcs on cylinders. Keep cylinders away from direct heat, flame and sparks.

## SAFETY PRECAUTIONS

continued



**WARNING! Electrical shock can kill.** Make sure all electrical equipment is properly grounded. Do not use frayed, cut or otherwise damaged cables and leads. Do not stand, lean or rest on ground clamp. Do not stand in water or damp areas while welding or cutting. Keep work surface dry. Do not use welder or plasma cutter in the rain or in extremely humid conditions. Use dry rubber soled shoes and dry gloves when welding or cutting to insulate against electrical shock. Turn machine on or off only with gloved hand. Keep all parts of the body insulated from work, and work tables. Keep away from direct contact with skin against work. If tight or close quarters necessitates standing or resting on work piece, insulate with dry boards and rubber mats designed to insulate the body from direct contact.



**All work cables, leads, and hoses pose trip hazards.** Be aware of their location and make sure all personnel in area are advised of their location. Taping or securing cables with appropriate restraints can help reduce trips and falls.



**WARNING! Fire and explosions are real risks while welding or cutting.** Always keep fire extinguishers close by and additionally a water hose or bucket of sand. Periodically check work area for smoldering embers or smoke. It is a good idea to have someone help watch for possible fires while you are welding. Sparks and hot metal may travel a long distance. They may go into cracks in walls and floors and start a fire that would not be immediately visible. Here are some things you can do to reduce the possibility of fire or explosion:

- Keep all combustible materials including rags and spare clothing away from area.
- Keep all flammable fuels and liquids stored separately from work area.
- Visually inspect work area when job is completed for the slightest traces of smoke or embers.
- If welding or cutting outside, make sure you are in a cleared off area, free from dry tender and debris that might start a forest or grass fire.
- Do not weld on tanks, drums or barrels that are closed, pressurized or anything that held flammable liquid or material.



**Metal is hot after welding or cutting!** Always use gloves and or tongs when handling hot pieces of metal. Remember to place hot metal on fire-proof surfaces after handling. Serious burns and injury can result if material is improperly handled.



**WARNING! Faulty or poorly maintained equipment can cause injury or death.** Proper maintenance is your responsibility. Make sure all equipment is properly maintained and serviced by qualified personnel. Do not abuse or misuse equipment.



Keep all covers in place. A faulty machine may shoot sparks or may have exploding parts. Touching uncovered parts inside machine can cause discharge of high amounts of electricity. **Do not allow employees to operate poorly serviced equipment.** Always check condition of equipment thoroughly before start up. Disconnect unit from power source before any service attempt is made and for long term storage or electrical storms.



Further information can be obtained from The American Welding Society (AWS) that relates directly to safe welding and plasma cutting. Additionally, your local welding supply company may have additional pamphlets available concerning their products. Do not operate machinery until your are comfortable with proper operation and are able to assume inherent risks of cutting or welding.



**PowerPlasma 60S/80S/100S**



Regulator Assembly with Bracket



Consumable Starter Kit  
(Qty. and items may vary)



Work Clamp



iPT 60/80/100 Torch

NOTE: Accessory and consumable style and quantities are subject to change without notice.

## SECTION 1

## INTRODUCTION AND SPECIFICATIONS

| Specification  | PowerPlasma 60S                                   | PowerPlasma 80S                                   | PowerPlasma 100S                                  |
|--|---|---|---|
| Inverter Type  | IGBT  | IGBT  | IGBT  |
| Minimum/Maximum Rated Output   | 20 A/88 V - 60 A/108 V                            | 20 A/88 V-80 A/112 V                              | 20/88V  |
| Start Type   | Blow-Back Type                                    | Blow-Back Type                                    | Blow-Back Type                                    |
| Torch Type   | Innotec iPT60                                     | Innotec iPT80                                     | Innotec iPT100                                    |
| Duty Cycle @ Rated Amps/Volts ( 40° C)<br>(Output V/A)                           | 60% @ 60 A/ 104V<br>100% @ 50 A/ 100 V            | 60% @ 80 A/112 V<br>100% @ 63 A/104 V             | 60% @ 100 A/ 120V<br>100% @ 80A/112V              |
| OCV (U0)   | 240 V   | 240 V   | 250V  |
| Voltage Input (U1)   | Standard 220/ 240 V;<br>50/60Hz 1 Ph              | Standard 220/ 240 V;<br>50/60Hz 1 Ph              | Standard 220/240V;<br>50/60Hz 1 Ph(3 Ph. Opt)     |
| Maximum Inrush Amps (I1MAX)  | 41 A @ 240 V                                      | 58.4 A @ 240 V                                    | 78A/45A @ 240V 1Ph/3Ph                            |
| Maximum Rated Effective Amps (I1EFF)   | 32.4 A @ 240 V                                    | 45.2 A @ 240 V                                    | 60/35 @ 220V 1ph/3ph                              |
| CNC Port   | Yes   | Yes   | Yes   |
| Air Post Flow Timer  | Adjustable  | Adjustable  | Adjustable  |
| Minimum Air Compressor Requirement   | 5.5 CFM @ 90 psi/<br>30-60 gallon reserve         | 7 CFM @ 90 psi/<br>30-60 gallon reserve           | 8 CFM @ 90 psi/<br>60 gallon reserve              |
| Duty Cycle/ Over Current Protection  | Yes   | Yes   | Yes   |
| Minimum Operating Air Pressure<br>(Safety Cut-Out Threshold)                     | 35 psi  | 35 psi  | 35 psi  |
| Recommended Operating Air Pressure<br>(Set with Air Flow set to "Constant Flow") | 70-75 psi   | 70-75 psi   | 70-75 psi   |
| Maximum Permissible Static Air Pressure<br>(Without air flowing)                 | 85 psi  | 85 psi  | 85psi   |
| Maximum Supplied Air Pressure<br>(From Compressor/Tank)                          | 90 psi  | 90 psi  | 90 psi  |
| Recommended Daily Maximum Average Daily<br>Cut Thickness (Hand Torch)            | 5/8"  | 1"  | 1 1/4"  |
| Recommended Daily Maximum Average Cut<br>Thickness (CNC)                         | 3/8"  | 5/8"  | 7/8"  |
| Rated Maximum Quality Cut @10-12 IPM<br>(Steel)                                  | 1"  | 1 1/4"  | 1 3/8"  |
| Max Severance Cut @ 3 IPM (Steel )   | 1 1/4"  | 1 7/16"   | 1 5/8"  |
| Minimum Water Ingress Protection Standard  | IP21S   | IP21S   | IP21S   |
| Efficiency   | >85%  | >85%  | >85%  |
| Cooling Method   | Full Time High Velocity Fan<br>with Tunnel Design | Full Time High Velocity Fan<br>with Tunnel Design | Full Time High Velocity Fan<br>with Tunnel Design |
| Dimensions (approximate)   | 18" H X 10" W X 25" L                             | 18" H X 10" W X 25" L                             | 18" H X 10"W X 25"l                               |
| Weight (Bare Unit)   | 55 lbs  | 55 lbs  | 58 lbs  |

Decrease maximum cut thickness values for aluminum and stainless by approximately 40%.

When evaluating a plasma cutter for daily service, do not consider maximum severance cut values as criteria for routine use! These maximum specifications are intended for occasional situations that might require such a cut. Plan the unit's daily use around the recommended average cut thickness for best results and speed. This is an industry standard recommendation and is not unique to Everlast PowerPlasma models. CNC cut thickness is further reduced as it is typically a 100% duty cycle operation which will require a lower maximum amp setting. Plasma performance specifications are based on reasonable environmental conditions with well maintained units, and cutting with new consumables using optimum air pressure. Actual performance results may vary in the field due to variable conditions, power supply, air pressure, air quality, consumable wear etc.

## SECTION 1

## INTRODUCTION AND SPECIFICATIONS

**General overview:** The new, redesigned PowerPlasma S series are non-high frequency start machines. The “blow-back” type start that is used is generally safe for use in CNC applications and is ideal for general use. The elimination of the HF points within the unit also improves reliability and removes the need for regular HF point gap maintenance. Blow-back type start involves a rear-ward movement of the electrode within the torch head when forced by the air pressure. When air pressure is applied the movement of the electrode off its seated position against the inner surface of the circuit grounded nozzle creates a spark, energizing the plasma stream. This type start means that it has a pilot arc design so that cutting can be done on any metal surface without having to contact to strike an arc and is ideal for cutting items like expanded metal or uneven surfaces. There are several other key features on the PowerPlasma S series:

- A. IGBT construction is designed to improve reliability while providing power. By using mostly non proprietary components long term serviceability is ensured.
- B. Full bridge design features soft switching technology which further extends IGBT component life and extends its capabilities.
- C. The Italian designed PT/iPT series of torches features a “blowback” design with a Euro-type Central connector. These offer improved consumable life with a patented “back striking” design.
- D. The Tip Saver feature further improves consumable life by limiting the pilot arc on time to 3 seconds. A normal mode is also available for extended cutting on expanded/perforated metal and irregular surfaces. In the tip saver mode, once the pilot arc has been engaged for 3 seconds the pilot arc will extinguish and the trigger must be cycled to restrike.
- E. Manual post-flow control is a unique feature with Everlast and provides better post flow control of the air so consumable life is increased and the torch can be cooled for an extended period of time if desired.
- F. OK-to-Cut light stays lit while the plasma cutter is within the minimum air pressure limits needed for the torch to function without causing torch damage. If the light goes out, the automatic shut down terminates the output of the unit until the air pressure is back to a sustainable level. Minimum air pressure is set around 35 psi. Keep in mind this air pressure is not ideal, but will prevent premature torch failure.

**General Use and Care:** The Plasma cutter is designed for use in many industrial environments such as ship yards, fabrication shops and pipelines. However, care should be taken to keep the unit out of direct contact with water spray. The unit is rated IP21S, which rates it for light


contact with dripping water. It is a good idea to remove the welder from the vicinity of any water or moisture source to reduce the possibility of electrocution or shock. Never operate in standing water. This unit has a high open circuit voltage further necessitating safe operating practices. The operator should be careful to prevent splashing/spraying water in the direction of the plasma cutter. Every 1-2 months, depending upon use, the welder should be unplugged, opened up and carefully cleaned with dry, compressed air. Regular maintenance will extend the life of the unit. Always protect the unit from low temperatures (<-10°F/-23°C). Do not operate below 15°F/9°C Do not restrict air flow or movement of air around the plasma cutter. Allow a buffer distance of 2 ft. from all sides if possible, with a minimum distance of at least 18” clearance. Do not direct metallic dust or any dirt intentionally toward the machine, particularly in grinding and cutting operations. Every three months, remove the cover and blow out the interior with compressed air to remove buildup (use safety glasses to protect your eyes). **Before opening the unit for service, make sure the unit has been unplugged for at least 10 minutes to allow time for the capacitors to fully discharge. Severe shock and/or death can occur.** During use and storage, make sure the panel is protected from damage during welding and cutting operations by flipping down the clear protective cover.

**Duty Cycle.** The duty cycle for the PowerPlasma S series units are rated for 60% while operating at the maximum amps output. The duty cycle is based off a 10 minute duty cycle rating at 40° C. This means that the unit is capable of being operated at the maximum stated amps for 6 out of every 10 minutes without a break to cool down the unit. This does NOT mean that the unit can work 60% of any greater length of time. A full 4 minute rest is needed for maximum life. The temperature light will come on and the welder will automatically stop welding when an over-heat condition has occurred. Heat will continue to be generated by and transferred to the electronics after cutting has ceased. If an overheat event occurs, allow the unit to cool for 15-20 minutes before resetting the unit. Do not shut down an overheated cutter before resuming cutting. Operation in humid, or hot conditions can affect duty cycle as well. Once the overheated condition has cleared, reset the unit by cycling the power switch to off and then back on. Do not operate the plasma cutter with the covers removed for safety and overheating concerns.


### IMPORTANT:

**This manual has been compiled to give an overview of operation and is designed to offer information centered around safe, practical use of the plasma cutter. Do not operate this machine until you have fully read the manual, including the safety section.**

**QUICK SETUP GUIDE: CONNECTIONS**




**QUICK SETUP GUIDE: REAR CONNECTIONS AND WIRING  
(US/Canada)**




## QUICK SETUP GUIDE: REAR CONNECTIONS AND WIRING

### Compressor and Dryer Diagram



**NOTE:** A SEPARATE AIR DRYER BETWEEN THE AIR COMPRESSOR AND REGULATOR ASSEMBLY MUST BE INSTALLED. IT SHOULD BE INSTALLED AS CLOSE TO THE PLASMA CUTTER AS PRACTICAL. THIS IS A CUSTOMER SUPPLIED ITEM. THIS WILL REDUCE CUTTING ISSUES SUCH AS SPITTING, POPPING AND RAPID CONSUMABLE WEAR. THE REGULATOR/FILTER THAT IS INCLUDED IS NOT SUFFICIENT TO REMOVE ALL MOISTURE. IT SERVES ONLY AS A WATER TRAP AND FINE SEDIMENT FILTER. ANY AIR COMPRESSOR SYSTEM PRODUCES MOISTURE IN ALMOST ANY ENVIRONMENT REGARDLESS OF HUMIDITY LEVELS. DRAIN THE AIR COMPRESSOR DAILY. THE AIR SUPPLIED TO THE PLASMA CUTTER SHOULD BE OF SIMILAR QUALITY USED FOR AUTOMOTIVE PAINTING. DIFFERENT STYLES OF DRYERS ARE AVAILABLE. THE MOST INEXPENSIVE AND COMMONLY AVAILABLE AIR DRYER IS THE REPLACEABLE DESSICANT TYPE USED FOR AUTOMOTIVE PAINTING. DAMAGE DONE TO THE TORCH AND THE PLASMA CUTTER (INCLUDING BUT NOT LIMITED TO: SHORTING, CORROSION AND DETERIORATION OF INTERNAL LINES AND COMPONENTS) AS A RESULT OF EXCESS MOISTURE IS NOT COVERED UNDER WARRANTY. ADDITIONALLY, A FILTER SHOULD BE INSTALLED IN-LINE OR AT THE COMPRESSOR THAT WILL FILTER ANY EXCESS OIL OR OIL BLOW-BY FROM THE LINE IF NECESSARY. **DO NOT USE THE PLASMA CUTTER WITH OILING SYSTEMS DESIGNED TO AUTOMATICALLY LUBRICATE AIR TOOLS.** FOR BEST RESULTS, USE THE PLASMA CUTTER WITH A NEW AIR SUPPLY HOSE GUARANTEE THE AIR SUPPLY IS INITIALLY WITHOUT MOISTURE OR LUBE CONTAMINATION. IF THE AIR PRESSURE DROPS FROM THE COMPRESSOR TO THE CUTTER MORE THAN 5-10 PSI, OR AIR FLOW IS INSUFFICIENT, INCREASE TO A LARGER SIZE DRYER, FILTER OR AIR HOSE. FAILURE TO USE THE PROPER DRYER OR FILTER IS THE NUMBER ONE CAUSE OF CUTTING ISSUES RELATED TO CONSUMABLE WEAR.

FRONT PANEL FEATURES AND CONTROLS




## FRONT PANEL FEATURES AND CONTROLS CONTINUED

| PowerPlasma S Features        | Parameters                 | Purpose   |
|-------------------------------|----------------------------|---|
| 1. Amp Display                | 20-60 (60S)<br>20-80 (80S) | Displays selected amperage until cut starts. Once cut starts, then amps display dynamically by displaying the actual output amps while cutting. While Pilot arc is engaged or when cut starts, the amps will drop to 20-30 amps until continuity is sensed and cutting arc takes over and the pilot arc disengages.   |
| 2. Air Pressure OK to Cut LED | On/Off                     | This light should remain on as long as there is sufficient cutting pressure to protect the torch from melting. Once the air pressure drops below the minimum threshold of approximately 35 psi, the light will go out, indicating the pressure is too low. If the light goes out the unit will automatically prevent the torch arc from being activated and there will be no power to the torch. The unit will not cut until the minimum air pressure is satisfied.   |
| 3. Air Pressure Gauge.        | 0-150 psi                  | The gauge registers up to 150 psi, but air pressure from the compressor to the cutter should never be set above 90 psi. Air pressure to the torch while cutting should ideally be around 75 psi.  |
| 4. Amp Control                | Infinite                   | Adjusts and selects desired operating amperage.   |
| 5. Central Torch Connector    | N/A                        | The central torch connector is an all-in-one connector. This is a universal style connection which allows greater interchangeability of torches. It also greatly simplifies torch connection. When installing the connector, line up the locating tab on the torch side with the slot on the connector on the machine side connector. Fully insert the coupling and then tighten the collar nut on the torch-side fitting hand tight. Do not use tools to tighten. Do not over tighten.   |
| 6. Fuse                       | 30 A<br>(Slow Blow Type)   | This fuse protects the unit from overloads of the pilot arc. If the pilot arc ceases to operate, check the fuse and replace it if it is faulty. This is a standard glass type automotive fuse which can be sourced locally. Do not use a higher rating than what the old fuse is rated for or damage can occur.   |
| 7. Work Piece Connector       | N/A                        | The work lead (sometimes referred to as "ground") is used to complete the circuit. The torch pilot arc may activate, but the unit will not actually cut if the work lead is not connected to the work piece. If an arc is present but the unit will not easily cut or is very slow or poor cutting any material, check and make sure work lead is connected and is connected to a clean spot on the work.   |
| 8. Air Post Flow              | 0-60 Seconds               | Select a post flow time that is appropriate to cool the torch and the consumables. Post flow time will depend upon the amps and length/severity of use. A post flow time of 1 second post flow for every 10 amps is suggested.  |
| 9. 2T/4T Trigger lock         | 2T/4T                      | 2T is the normal position while cutting. To operate, simply press and hold the switch and cut normally. Release the switch when the cut is finished. The 4 T setting allows the torch to be locked on during use. To cut in 4T mode, simply press and hold the trigger to start the arc. Release the trigger to continue cutting. Once the arc is ready to be terminated slowly press and release the switch again. <b>Caution:</b> Use 4T cautiously. This feature can leave the torch activated if the torch is improperly withdrawn from the cutting area. But is useful for long cuts or when mechanical cutting requiring remote activation of the torch, i.e. a linear track torch or a pipe bevel track cutter.  |
| 10. Pilot Arc Function        | Tip Saver/<br>Normal       | This allows the user to choose the best pilot arc mode to save consumables. The 3 second pilot arc will only engage the pilot arc for 2-3 seconds before it shuts the arc off. To re-fire the pilot arc in tip saver mode, release the trigger and press it again. Normal mode allows the pilot arc to automatically re-engage after cutting continuity is lost, i.e. cutting expanded metal.   |
| 11. Air Flow Function         | Test/Normal                | Select "Test" to set air flow/air pressure for the torch. The operating pressure should always be set while this is in Test since it does not require the torch to be live. This allows the air to flow constantly until the switch is placed back into the normal, timed mode. To set the air pressure, turn the torch until the nozzle is facing up, then place the flow tube (clear plastic tube with ball in it) over the nozzle. Select "Test" on the machine. With the air flowing, adjust the air pressure/flow up or down until the ball is floating in the sight window of the flow tube. If no flow tube is present or provided with your unit, then simply set the air pressure while "Test" is selected until it is somewhere between 70-75 psi. Pressure over or under this can result in an unstable arc.   |
| 12. On/ Temp/ Over Current    | On or Off                  | These indicate the status of the machine and indicate if any fault is present. If duty cycle is exceeded, the Duty Cycle light will come on and cutting will be interrupted, but the unit will continue to run and the fan will cool. Once the light goes off cutting may resume. After 5-10 minutes, if the light does not go off and cutting is still prevented, the cycle the machine off and then back on. If the Over Current light is on, recheck all wiring and connections and make sure the correct wire size and wiring has been used. Purposefully creating too long of an arc may also cause this or it could be a side-effect of hitting the duty cycle limit of the machine. Cycle the machine on and off. If the light clears and cutting resumes, the fault has been cleared. If the unit will not work and/or the light remains on, contact Everlast Tech Support. |



**REAR PANEL FEATURES AND CONTROLS**



## REAR PANEL FEATURES AND CONTROLS CONTINUED



| PowerPlasma S Features   | Parameters  | Purpose  |
|--------------------------|---|--|
| 1. CNC Connection        | N/A   | This allows the unit to be used with a CNC machine and provides the basic inputs for CNC operation. See pin-out section located in the back of this manual.  |
| 2. 2-Pole Power Switch   | On/Off  | The 2 pole breaker switch serves as the On/Off switch for the cutter. Always turn the cutter on and off by the switch first before using any disconnect switch.  |
| 3. Power Cable with Plug | 220/240 V<br>1 phase<br>(110 X2)<br>Plug:<br>NEMA 6-50P | The PowerPlasma 60S and 80S S will operate on 220/240 V 50/60 Hz power, including good quality 208 V power. The wiring contains 3 separate wires. Everlast uses standard sized wiring and correct plugs (NEMA 6-50P) for welders and plasma cutters in the US and Canada. (Other countries will vary according to regional requirements). Standard wire colors are L-1 black (hot), L-2 white (hot), and green (ground) for 1 phase 220/240 V. Do not attempt to use a 4 wire 1 phase 220/240 connection. <b>NOTE: In many home circuits, red and black are the power wires. But in standard welding/ plasma cutting circuitry, white and black are hot wires. Green is always the ground in both circuits. There is NO neutral in a standard welder circuit. The units are shipped with a standard NEMA 6-50P plug.</b> Always consult a licensed electrician who is aware of local codes before attempting any wiring of the welder or of the power supply circuits. Everlast is not responsible for any mis-wiring or damage caused to the unit by incorrectly wiring the welder. If additional help is needed, contact Everlast. <b>Disconnect the plasma cutter when not in use.</b>  |
| 4. Gas Input Connection  | N/A   | The gas input line is connected to the regulator assembly via the clear tubing provided in the accessory package. To attach, simply push the tubing into the connector until it is firmly seated then give a slight tug to make sure it has been captured correctly by the fitting. Make sure that the tubing shoulder is squarely cut and not cut at an angle. An uneven or angular cut will cause leaking at the connector. If the tubing must be removed, simply push on the outer plastic collar back and retract the tubing while holding it in the other hand.   |
| 5. HF Ground Bolt        | N/A   | High Frequency (HF) energy can be devastating to surrounding electronic equipment. Although this unit does not use HF energy to start the arc, normal HF generated by the unit may cause slight interference with electronic items. This bolt can serve as a direct drain should any EMF interference is suspected.  |
| 6. Regulator Assembly    | N/A   | The regulator assembly serves as both as an air filter, water trap, and pressure regulator. The water trap with the fine sediment filter is self draining. It is not designed to dry the air, but rather serves the purpose of catching any residual slug of water that may be present in the air line and filtering any trash or sediment that passes into the bowl of the regulator. It is not designed to serve as an air dryer. A separate air dryer must be placed between the regulator and the air compressor. During the assembly of the regulator, be sure to screw the 1/4" automotive quick connect into the side that is stamped on top with "IN" or that has been stamped with an arrow pointing to the center of the regulator. The small brass plug should screw into the center of the regulator and the remaining push-to-connect fitting should be screwed into the remaining hole. Then, connect the clear tubing to the push-to-connect. Make sure the shoulder of the tubing has been cut squarely or the connection may leak as a result. Screw the regulator bracket to the back of the plasma cutter first before attaching the regulator to the bracket. Make sure the screws located in the accessory bag are the proper length and are inserted with the accompanying lock and flat washers. To adjust the regulator, simply pull the knob up slightly until it clicks, and rotate the knob clockwise to increase the pressure or counter clockwise to decrease the pressure. To lock in the setting, push the knob down until it clicks. Do not exceed 90 psi supply pressure. Do not exceed 85 psi on the plasma cutter side of the regulator or internal leakage may result. Operating air pressure should be set to about 75 psi while in to "Test" mode. |

- Never operate the plasma cutter on a generator that is not certified by its manufacturer to be "clean" power, which is less than 10% total harmonic distortion. Less than 5% THD is preferred. Operating the unit on square wave output or modified sine wave generators is strictly prohibited. Contact the manufacturer of the generator for this information. Everlast does not have an "approved" list of generators. But, if the generator is not listed as clean power by its manufacturer, then operation is prohibited. Generators that do not at least meet the operating input requirements of the plasma cutter are also forbidden to be used with the unit. Surge amp capability of the generator should equal or exceed the maximum inrush demand of the plasma cutter. But the surge capability should not be used as the only factor. The regular, running output of the generator should match or exceed the running or "rated" demand of the welder. Any damage done by operating the unit on a generator not specified by its manufacturer to be "clean", will not be covered under warranty. This also includes suspect power sources where voltage is below 208 V and above 249 V.
- To properly size the breaker, the I1MAX should be used in determining breaker size. To size the wiring, the I1EFF rating should be used to help determine the proper wire size. The NEC in Article 630.11 allows a derating of the wire size based off of duty cycle. The requirements are different than the requirements for most other 240V electrical products. However, consult a licensed electrician and local codes before installing any wiring or breakers.

## SECTION 3

## BASIC THEORY AND FUNCTION

The design of the blow back start *may* cause a slight delay in the arc as the air pressure must built inside the torch tubing and head to create the pressure needed to force the electrode off the nozzle seat. This may take up to a second. Restarting the arc in tip saver mode requires retriggering the torch. If the torch does not light after 3 seconds, let go of the trigger and press it again. If the start or arc is erratic check nozzle and electrode for tightness and wear.



Edge Starts are the best type of start if possible to promote consumable and torch life. This reduces blow back of molten material and allows a smooth gradual start of the cut.




1. Line up the hole on the tip of the electrode on the edge of the cut. Hold torch perpendicular to the cut initially, about 1/16" off the metal. Slide the yellow safety lock and squeeze the trigger. Wait for arc to start.
2. Once the arc starts, wait for the arc to penetrate all the way through the metal.
3. As the torch penetrates its flame all the way through the metal, tilt the torch so there is a slight lead in the flame if metal is thin. If it is thick, keep holding torch in a nearly vertical position.
4. Begin moving the torch in the direction of the cut. Maintain 1/16" standoff height.
5. Move the torch fast enough so the sparks and flame trail from the bottom edge at an angle of no more than 30° and no less than 10° from perpendicular to the metal. Excess angle of sparks/flame indicate too fast of travel speed or practical cut capacity has been reached. Little or no angle indicates too slow of travel speed.

Piercing starts often result in rapid consumable wear and excess blow back of molten metal deposited onto torch and consumables. This should be done only as necessary.

1. Tilt the torch in the direction of travel or toward the side of the metal to be discarded or wasted at a 40° to 60° angle. Slide the yellow safety lock and squeeze the trigger. Wait for arc to start.
2. Once the arc starts, wait for the arc to transfer from pilot arc to the cutting arc.
3. As the torch penetrates it flame at an angle rotate the torch slowly to the vertical position, as the arc penetrates the metal. Tilt the torch from 0°-15° for thin metal cuts, or hold it nearly perpendicular for thicker metal cuts.
4. Begin moving the torch in the direction of the cut. Maintain 1/16" standoff height.
5. Move the torch fast enough so the sparks and flame trail from the bottom edge at an angle of no more than 30° and no less than 10° from perpendicular to the metal. Excess angle of sparks/flame indicate too fast of travel speed or practical cut capacity has been reached. Little or no angle indicates too slow of travel speed.

**IMPORTANT:** If you use a standoff guide with the torch, it must be adjusted to provide no more than 1/8" standoff, less if possible. Long stand-off heights reduce cut capacity and quality. It also promotes rapid consumable wear and can prevent the pilot arc from transferring.


**TIP:** For longer consumable life do not use the pilot arc unnecessarily. Select the 3 second pilot arc feature and do not fire the torch unless you are near the metal and ready to cut. For expanded metal cutting be sure to select "Normal" to re-fire the pilot arc automatically.



**NOTE:** When stepping down amps to cut thinner material, you must change to smaller orifice nozzle. Nozzles are offered in different sizes which are appropriate for different amp levels. Too large of a diameter orifice will result in arc instability and a rough cut. Lowering the air pressure below 65 psi to try to get the torch to cut will only result in a lazy, wandering arc.


**IMPORTANT:** Check consumables regularly for wear and change them out before they are completely worn. Allowing the consumables to wear until they quit working may damage related torch components, creating a more costly repair.

**RESULTS OF CUT AT CORRECT SPEED,  
AIR PRESSURE AND TORCH ANGLE**  
SMOOTH, EVEN CUT LINES WITH A S REARWARD SWEEP




MINIMAL EASY TO CLEAN DROSS

**RESULTS OF CUT AT FAST SPEED**  
ROUGH, DISTINCT CUT LINES SPACED FAR APART




NOTICEABLE SMALL, HARD DROSS

**RESULTS OF CUT AT SLOW SPEED**  
VERTICAL CUT LINES




SIGNIFICANT SOFT, POROUS DROSS


**RESULTS OF TOO MUCH CURRENT OR  
TOO MUCH STAND OFF HEIGHT  
(SIDE VIEW)**  
MELTED TOP EDGE




**RESULTS OF WORN CONSUMABLE OR  
LOW AIR PRESSURE  
(SIDE VIEW)**  
SEVERLY ANGLED CUT AT TOP





AN EXAMPLE OF CUTTING A LEAD-IN WHEN CUTTING OUT A DISK SHAPED OBJECT



AN EXAMPLE OF CUTTING A LEAD-IN WHEN CUTTING HOLE IN AN OBJECT



When cutting an object, particularly a pattern shape, where the torch must pierce or re-fire in-line at an intersection of a cut, a lead-in cut should be employed. A lead-in is a cut that is made in the disposable part (also known as a drop) of the object to “lead” into the main part of the cut so that the destructive force of the arc is not directed into the desirable side of the cut itself. Also, all plasma cutters exhibit some angularity or bevel in the cut which is greater on one side than the other. Keep this in mind when cutting an object to size so that too much metal is not accidentally removed.




| Technical Data  | 技术参数               |
|-----------------|--------------------|
| Current         | 60Amp              |
| Duty Cycle      | 60%                |
| Gas             | Air/N <sub>2</sub> |
| Gas Pressure    | 4.4-5.0 Bar        |
| Gas Flow        | 110 LPM            |
| Ignitor         | Without HF         |
| Post Flow       | 55sec. recommended |
| Standard Length | 6M                 |





| Position       | Code       | Ref.      | Description   |
|----------------|------------|-----------|---|
| 1              | ISM0098    |           | Double pointed spacer/IPT60                         |
| 2              |            |           | Outside nozzle                                      |
| 2.1            | IVS0661    | PC0116    | Outside nozzle 6 holes                              |
| 2.2            | IVS0663    |           | Outside nozzle 6 holes/maximum life                 |
| 3              |            |           | Tip   |
| 3.1            | IVU0661-06 | PD0116-06 | Tip $\Phi$ 0.6mm/IPT25-60/10-20A                    |
| 3.2            | IVU0661-08 | PD0116-08 | Tip $\Phi$ 0.8mm/IPT25-60/20-30A                    |
| 3.3            | IVU0661-09 | PD0116-09 | Tip $\Phi$ 0.9mm/IPT25-60/30-40A                    |
| 4              |            |           | Tip   |
| 4.1            | IVU0660-06 |           | Tip $\Phi$ 0.6mm/10-20A/back striking               |
| 4.2            | IVU0660-08 |           | Tip $\Phi$ 0.8mm/20-30A/back striking               |
| 4.3            | IVU0660-09 |           | Tip $\Phi$ 0.9mm/30-40A/back striking               |
| 4.4            | IVU0660-10 |           | Tip $\Phi$ 1.0mm/40-50A/back striking               |
| 5              | IVU0668-09 |           | Tip $\Phi$ 0.9mm/30-40A/IPT60/back striking         |
| 6              |            |           | Flat tip  |
| 6.1            | IVU0668-10 |           | Flat tip $\Phi$ 1.0mm/40-50A/back striking          |
| 6.2            | IVU0668-11 |           | Flat tip $\Phi$ 1.1mm/50-60A/back striking          |
| 7              |            |           | EXTended tip  |
| 7.1            | IVU0609-06 |           | EXTended tip $\Phi$ 0.6mm/10-20A/back striking      |
| 7.2            | IVU0609-08 |           | EXTended tip $\Phi$ 0.8mm/20-30A/back striking      |
| 8              | IVU0603-09 |           | EXTended tip $\Phi$ 0.9mm/30-40A/back striking      |
| 9              | IVF0601    | PE0106    | Diffuser IPT25-60                                   |
| 10             | IVB0660    | PR0110    | Electrode Plasma IPT25-40                           |
| 11             | IVB0048    |           | Electrode Plasma IPT25-60/back striking             |
| 12             | IVB0049    |           | Extended electrode Plasma IPT25-60/back striking    |
| 13             | IVZ0673    |           | Plasma torch head IPT60                             |
| 13a            | IFT0709    |           | "O"ring $\Phi$ 18x15mm                              |
| 14             | IGV0038    |           | Plasma handle manual/IPT20-60/Red                   |
| 15             | IHJ0722    |           | Protection part/Plasma/Yellow                       |
| 16             | IHQ0070    | 185.0031  | Trigger   |
| 17             | IHJ0898    |           | Joint/small/new type                                |
| 18             |            |           | Cable assembly                                      |
| 18.1           | IVN0806    |           | Cable assembly/IPT60/6m 1/4G Separated              |
| 18.2           | IVN0807    |           | Cable assembly/IPT60/6m central adaptor             |
| 18.3           | IVN0808    |           | Cable assembly/IPT60/6m 1/4G                        |
| 19             | ICG6006    |           | Spanner for Plasma                                  |
| 20             | IZX0078    | FY0023    | Central adaptor torch side Plasma 5 pins            |
| 21             | ISM0707    |           | Circle cutting attachment                           |
| Complete Torch |            |           |   |
| A              | IVT0847    |           | Plasma torch IPT60/6m 1/4G                          |
| A              | IVT0847-01 |           | Plasma torch IPT60/6m 1/4G back striking            |
| B              | IVT0848    |           | Plasma torch IPT60/6m 1/4G seperated                |
| B              | IVT0848-01 |           | Plasma torch IPT60/6m 1/4G back striking            |
| C              | IVT0846    |           | Plasma torch IPT60/6m central adaptor               |
| C              | IVT0846-01 |           | Plasma torch IPT60/6m central adaptor/back striking |






MACHINE TORCH  
(OPTIONAL FOR CNC)




**Technical Data**

|                 |                    |
|-----------------|--------------------|
| Current         | 80Amp              |
| Duty Cycle      | 60%                |
| Gas             | Air/N <sub>2</sub> |
| Gas Pressure    | 1.4-5.0 Bar        |
| Gas Flow        | 110 LPM            |
| Ignition        | Without HF         |
| Post Flow       | Up to 60 Seconds   |
| Standard Length | 6M                 |

| Position       | Code       | Ref.     | Description  |
|----------------|------------|----------|--|
| 1              | ISM0089    |          | Double pointed space IPT80                                 |
| 2              | IVS0667    |          | Outside nozzle IPT80                                       |
| 2.1            | IVS0667-01 |          | Outside nozzle/maximum life IPT80                          |
| 3              | IVU0671-09 |          | Tip $\Phi$ 0.9mm/30-40A/back striking                      |
| 4              |            |          | Tip  |
| 4.1            | IVU0670-10 |          | Tip $\Phi$ 1.0mm/40-50A/back striking                      |
| 4.2            | IVU0670-11 |          | Tip $\Phi$ 1.1mm/50-60A/back striking                      |
| 4.3            | IVU0670-12 |          | Tip $\Phi$ 1.2mm/60-70A/back striking                      |
| 4.4            | IVU0670-13 |          | Tip $\Phi$ 1.3mm/70-80A/back striking                      |
| 5              | ISM0700    |          | Shield cap hand/40-70A                                     |
| 6              | IVS0672    |          | Outside nozzle IPT80/Contact cut                           |
| 7              |            |          | Tip  |
| 7.1            | IVU0679-10 |          | Tip $\Phi$ 1.0mm/40-50A/back striking                      |
| 7.2            | IVU0679-11 |          | Tip $\Phi$ 1.1mm/50-60A/back striking                      |
| 7.3            | IVU0679-12 |          | Tip $\Phi$ 1.2mm/60-70A/back striking                      |
| 7.4            | IVU0679-13 |          | Tip $\Phi$ 1.3mm/70-80A/back striking                      |
| 8              | ISM0064    | 60508    | Shield cap gouging   |
| 9              | IVU0675-16 |          | Tip gouging/80A/back striking                              |
| 10             | IVF0665    |          | Diffuser IPT80   |
| 11             | IVB0669    |          | Electrode Plasma IPT80/back striking                       |
| 12             | IVZ0674    |          | Plasma torch head IPT80                                    |
| 12a            | IFT0709    |          | "O"ring $\Phi$ 18x15mm                                     |
| 12b            | IZN0773    |          | Air tube/IPT80   |
| 13             | IGV0031    |          | Plasma handle manual/IPT80-100/Red                         |
| 14             | IHJ0722    |          | Protection part/Plasma/Yellow                              |
| 15             | IHQ0070    | 185.0031 | Trigger  |
| 16             | IHJ0898    |          | Joint/small/new type                                       |
| 17             |            |          | Cable assembly   |
| 17.1           | IVN0801    |          | Cable assembly/IPT80/6m 1/4G                               |
| 17.2           | IVN0802    |          | Cable assembly/IPT80/12m 1/4G                              |
| 17.3           | IVN0803    |          | Cable assembly/IPT80/6m/central adaptor                    |
| 17.4           | IVN0804    |          | Cable assembly/IPT80/12m/central adaptor                   |
| 18             | IVZ0683    |          | Plasma torch auto head/IPTM80                              |
| 18a            | IGV0017    |          | Fiberglass position tube/IPTM80-120                        |
| 19             | ICG8006    |          | Spanner for Plasma   |
| 20             | IZX0078    | FY0023   | Central adaptor torch side Plasma 5 pins                   |
| 21             | ISM0708    |          | Circle cutting attachment IPT80                            |
| Complete Torch |            |          |  |
| HAND TORCH     |            |          |  |
| A              | IVT0911    |          | Plasma torch IPT80/12m 1/4G/back striking                  |
| A              | IVT0916    |          | Plasma torch IPT80/6m 1/4G/back striking                   |
| B              | IVT0912    |          | Plasma torch IPT80/6m central adaptor/back striking        |
| B              | IVT0917    |          | Plasma torch IPT80/6m central adaptor/back striking        |
| MACHINE        |            |          |  |
| A              | IVT0921    |          | Plasma auto torch IPTM80/12m 1/4G/back striking            |
| A              | IVT0926    |          | Plasma auto torch IPTM80/6m 1/4G/back striking             |
| B              | IVT0922    |          | Plasma auto torch IPTM80/12m central adaptor/back striking |
| B              | IVT0927    |          | Plasma auto torch IPTM80/6m central adaptor/back striking  |




**MACHINE TORCH (OPTIONAL FOR CNC)**



| Technical Data  |                    |
|-----------------|--------------------|
| Current         | 100Amp             |
| Duty Cycle      | 60%                |
| Gas             | Air/N <sub>2</sub> |
| Gas Pressure    | 4.6-5.0 Bar        |
| Gas Flow        | 200 LPM            |
| Ignition        | Without HF         |
| Post Flow       | Up to 60 Seconds   |
| Standard Length | 6M                 |

| Position              | Code       | Ref.   | Description  |
|-----------------------|------------|--------|--|
| 1                     | ISM0085    |        | Double pointed spacer/IPT100                               |
| 2                     | IVS0678    |        | Outside IPT100/30-70A                                      |
| 3                     | IVS0676    |        | Outside nozzle IPT100/80-120A                              |
| 4                     | IVU0672-09 |        | Tip $\phi$ 0.9mm/30-70A/back striking                      |
| 5                     |            |        | Tip  |
| 5.1                   | IVU0678-10 |        | Tip $\phi$ 1.0mm/40-50A/back striking                      |
| 5.2                   | IVU0678-11 |        | Tip $\phi$ 1.1mm/50-60A/back striking                      |
| 5.3                   | IVU0678-12 |        | Tip $\phi$ 1.2mm/60-70A/back striking                      |
| 6                     |            |        | Tip  |
| 6.1                   | IVU0676-14 |        | Tip $\phi$ 1.4mm/80-90A/back striking                      |
| 6.2                   | IVU0676-15 |        | Tip $\phi$ 1.5mm/100-110A/back striking                    |
| 6.3                   | IVU0676-16 |        | Tip $\phi$ 1.6mm/110-120A/back striking                    |
| 7                     | IVF0662    |        | Diffuser IPT100/30-70A                                     |
| 8                     | IVF0661    |        | Diffuser IPT100/80-120A                                    |
| 9                     | IVB0676    |        | Electrode plasma IPT100                                    |
| 10                    | ISM0700    |        | Shield cap/40-70A/Contact cut                              |
| 11                    | ISM0644    |        | Shield cap/80-120A   |
| 12                    | ISM0064    | 60508  | Shield cap,gouging/120A                                    |
| 13                    | IVS0674    |        | Outside nozzle PT100/Contact cut                           |
| 14                    |            |        | Tip  |
| 14.1                  | IVU0674-10 |        | Tip $\phi$ 1.0mm/40-50A/back striking                      |
| 14.2                  | IVU0674-11 |        | Tip $\phi$ 1.1mm/50-60A/back striking                      |
| 14.3                  | IVU0674-12 |        | Tip $\phi$ 1.2mm/60-70A/back striking                      |
| 15                    |            |        | Tip  |
| 15.1                  | IVU0686-14 |        | Tip $\phi$ 1.4mm/80-90A/back striking                      |
| 15.2                  | IVU0686-15 |        | Tip $\phi$ 1.5mm/100-110A/back striking                    |
| 15.3                  | IVU0686-16 |        | Tip $\phi$ 1.6mm/110-120A/back striking                    |
| 16                    | IVU0687-22 |        | Tip/gouging/120A/back striking                             |
| 17                    | IVZ0680    |        | Plasma torch head IPT100                                   |
| 17a                   | IZN0774    |        | Air tube IPT100  |
| 17b                   | IFT0705    |        | "O"ring $\phi$ 18x21mm                                     |
| 18                    | IGV0031    |        | Plasma handle manual/IPT80-100/Red                         |
| 19                    | IHU0722    |        | Protection part/plasma/Yellow                              |
| 20                    | IHQ0070    |        | Trigger  |
| 21                    | IHU0893    |        | Joint/small/new type                                       |
| 22                    |            |        | Cable assembly   |
| 22.1                  | IVN0801    |        | Cable assembly/IPT80-100/6m 1/4G                           |
| 22.2                  | IVN0802    |        | Cable assembly/IPT80-100/12m 1/4G                          |
| 22.3                  | IVN0803    |        | Cable assembly/IPT80-100/6m/central adaptor                |
| 22.4                  | IVN0804    |        | Cable assembly/IPT80-100/12m/central adaptor               |
| 23                    | ICG6006    |        | Spanner for Plasma   |
| 24                    | IVZ0684    |        | Plasma torch auto head/IPTM100                             |
| 24a                   | IGV0017    |        | Fiberglass position tube/IPTM80-120                        |
| 25                    | IZX0078    | FY0023 | Central adaptor torch side plasma 5 pins                   |
| 26                    | ISM0705    |        | Circle cutting attachment IPT100                           |
| <b>Complete torch</b> |            |        |  |
| <b>HAND TORCH</b>     |            |        |  |
| A                     | IVT0936    |        | Plasma torch IPT100/6m 1/4G/back striking                  |
| A                     | IVT0931    |        | Plasma torch IPT100/12m 1/4G/back striking                 |
| B                     | IVT0937    |        | Plasma torch IPT100/6m/central adaptor/back striking       |
| B                     | IVT0932    |        | Plasma torch IPT100/12m/central adaptor/back striking      |
| <b>MACHINE</b>        |            |        |  |
| A                     | IVT0946    |        | Plasma auto torch IPTM100/6m 1/4G/back striking            |
| A                     | IVT0941    |        | Plasma auto torch IPTM100/12m 1/4G/back striking           |
| B                     | IVT0947    |        | Plasma auto torch IPTM100/6m/central adaptor/back striking |

### CNC CONNECTOR PIN-OUT



Pins 1 and 2 activate (turn on) the plasma cutter.

Pins 9 and 10 gives the “OK to Move” signal. These are Dry “N.O.” style contacts. It is a non electronic switch that **closes** when the pilot arc transfers to cutting arc. Sometimes referred to as “Arc OK”.

Pins 5 and 7 provide the raw, undivided arc voltage, which is used by some controllers to adjust the height of the torch (THC). This is the actual cutting voltage. It runs through 2 -100KΩ resistors to prevent arcing at the connector plug. Some controllers may use the raw voltage, and is dependent upon the impedance of the input. CandCNC\* controller and Torchmate \* do not use this voltage.

Pins 4 and 6 provide the divided arc voltage. This is selectable by adding a jumper on the CNC circuit board to create either 1/16 th or 1/50th of the raw arc voltage. It may be used by some controllers for torch height control (THC). Usually the 1/16 setting is preferred.

Pin 3 is what some controller manufactures refer to as “Ground” this is connected directly to the work piece lead, which is actually a positive polarity. If the controller has a pin for ground this is likely the pin to use.

**NOTE: Do not connect anything directly to the output terminals or leads. Do not connect anything from the controller to the chassis of the cutter, especially a ground lead. Do not install any kind of converter or divider inside the machine.**

\*Everlast does not particularly endorse or recommend these brands and is not affiliated with them in anyway. They are mentioned as a common reference only. For specific recommendations regarding connection, contact the manufacturer of the CNC equipment/controllers.

**SECTION 4****TROUBLE SHOOTING**

| <b>TROUBLE:</b>   | <b>CAUSE/SOLUTION</b>  |
|---|--|
| Machine will not turn on. No fan, no display.   | Check cords and wiring in the receptacle. Check circuit breaker. Check plug condition.   |
| Air flows but arc does not start within 2-3 seconds.  | Check consumables for wear and tightness. Check fuse. Check Air Pressure. Sticky or slow spring/piston on torch blow back mechanism. Release trigger and try again.  |
| Air flows but pilot arc does not start or spark but arc starts when nozzle is rubbed on the metal.  | Fuse blown. Replace with 30 A automotive type, slow blow. PCB issue.   |
| OK to cut light is not on. Will not start arc.  | Increase air Pressure. Make sure air is connected.   |
| Pilot arc will not light. Arc will start when torch is drug on the metal.   | Fuse blown.  |
| Pilot arc will not transfer and amps read approximately 25-27 amps while switch is held. (Arc barely cuts or only "scratches" the surface of the metal or cut is extremely slow on thin materials.) | Check work clamp connection. Make sure rust is removed from work clamp contact area. Faulty Clamp. Arc continuity is not being sensed. If these steps do not correct the issue, contact Everlast.  |
| Arc Sputters.   | Inadequate air flow or air pressure. Improperly sized nozzle. Change to nozzle/Tip with smaller diameter orifice as amps are lowered. Increase air pressure to 73-75 psi while air is flowing through torch. Loose consumables. Check tightness. |
| Consumables are dirty, smutty looking upon inspection. Premature wear on consumables. Shortened consumable life. Tips are melted looking.   | Moisture, oil contamination of consumable. Wrong consumables. Poor quality aftermarket consumables. Drag cutting. Wrong cutting technique.   |
| Premature wear on consumables. Short consumable life. Uneven wear of consumables, melting of cup.   | Moisture, oil contamination of consumable. Excessive pilot arc time. Improper cutting technique. Wrong piercing technique.   |
| Arc will not start with pilot arc or by drag/scratch starting nozzle directly on metal. Machine runs.   | Torch cup is loose, safety contact pins dirty or not making contact with cup face. Torch switch wire is loose. Problem with Central connector. Torch is not properly connected. IGBT or PCB bad, contact Everlast.                               |
| Over current/Duty cycle LED illuminates. Machine runs, but no output.   | Duty cycle exceeded or Over current. Allow machine to cool. Reset main power switch after full cool down period. Make sure fan is not blocked. Check wiring.   |
| Unstable arc at lower amps.   | Nozzle orifice size is too large. Use nozzle with smaller orifice.   |
| Arc tries to start but irregular, dancing arc and/or arc melts through side of nozzle.  | Missing swirl ring, or worn electrode or both. Check and replace. Make sure swirl ring is not cracked.   |
| Arc will try to start if touched to the metal, but no air flow while switch is pressed.   | Stuck or dirty solenoid valve. Loose solenoid wire connection. Bad PCB. Contact Everlast.  |
| Air flows continuously. Erratic or unpredictable shutting off of air after post flow time has expired.  | Place switch into "normal" or "cut" mode. Reduce post flow time. Solenoid is stuck. Contact Everlast.  |
| Excessively Beveled Cut.  | Worn consumables, too high of stand-off height.  |
| Cup and/or nozzle is melting or cracking.   | Improper cutting technique/excessive piercing.   |
| Power input circuit breaker trips repeatedly.   | Improperly sized circuit. Internal issue. Contact Everlast.  |
| Arc "Blows Out" when ready to cut.  | Too high of air pressure. Reduce to 72 psi.  |

Having trouble setting up your unit for best cutting? Try the following:

- Keep your standoff to **less** than 1/8" distance from the work piece.
- Always use dry air. Drain compressor daily to improve effectiveness of air dryers and to prevent them from prematurely failing.
- Make sure work clamp is attached directly to the part being cut. Make sure the work clamp is attached to freshly cleaned metal.
- Don't greatly lower air pressure to try to reduce kerf or cut thinner material. Always reduce nozzle orifice size to match amperage. See Torch pages for different consumable sizes.
- Use this as a general rule of thumb for good hand cutting speed and quality:
  1. For the first 1/8" of thickness, use 20 amps.
  2. After the first 1/8" add 10 amps for every 1/8" after that.
  3. For Stainless and Aluminum, use settings that are 40% higher.



**STOP!**

**DO NOT TRIGGER THE TORCH TO SET AIR PRESSURE. SELECT "CONSTANT FLOW" MODE TO ADJUST AIR PRESSURE!**

**WARNING!**

**DO NOT CHANGE, ADJUST, OR REMOVE CONSUMABLES WHILE THE PLASMA CUTTER IS SWITCHED ON. TURN THE PLASMA CUTTER OFF BEFORE CHANGING CONSUMABLES. SERIOUS SHOCK, BURN OR INJURY MAY RESULT IF THE CUP SENSOR IN THE TORCH HEAD WERE TO MALFUNCTION OR FAIL! DO NOT RELY UPON THE CUP SAFETY CUT-OUT FEATURE TO PROTECT YOU AGAINST INJURY. DO NOT INTENTIONALLY FIRE THE TORCH WHILE CONSUMABLES ARE REMOVED.**

**Note about pilot arc operation:**

The pilot arc is not designed to be used to cut. The pilot arc is used to scour the surface to establish continuity so that the cutting arc will transfer. If you experience difficulty cutting and the arc seems to barely penetrate the metal, cutting speed is slow, or the consumable is wearing extremely fast, it is likely that the cutting arc has not engaged. While the pilot arc is engaged, the amperage is always going to be around 20-27 amps. If you notice the output amperage at this level while firing the torch or briefly before cutting, do not be alarmed. This is normal. The reduction in amperage prevents the consumables from being damaged. When continuity is sensed, the cutting amperage will increase as the arc transfers from torch to the metal. If amperage does not increase while cutting, and amperage is set over 27 amps, it is likely that the pilot arc is not transferring to the metal. Check for proper connection of the work clamp. Connect it directly to piece of metal being cut. Do not rely on an indirect connection through a work bench table. If necessary, grind a clean place on the metal to expose fresh, un-oxidized area of metal to make the best possible connection.

